



Quantum Chime

C1618C/C1618B




**C1618C/C1618B Component Detail:**

Note	Part Number	Description
1	<a href="#">PTC6618-BCA</a>	C1618C 1 ½" Chrome 18 Note Chime Tube Set



1	PTC6618-BA	C1618B 1 1/2" Brass 18 Note Chime Tube Set
2	PCC1618A	Frame Assembly Complete for C1618C/C1618B



**1. PTC6618-BCA Component Detail:**

Note	Part Number	Description
C5	PT608-B05CC	C5 Chime Tube (1 1/2" Chrome)
C#5	PT608-B55CC	C#5 Chime Tube (1 1/2" Chrome)
D5	PT608-B05DC	D5 Chime Tube (1 1/2" Chrome)
D#5	PT608-B55DC	D#5 Chime Tube (1 1/2" Chrome)
E5	PT608-B05EC	E5 Chime Tube (1 1/2" Chrome)
F5	PT608-B05FC	F5 Chime Tube (1 1/2" Chrome)
F#5	PT608-B55FC	F#5 Chime Tube (1 1/2" Chrome)
G5	PT608-B05GC	G5 Chime Tube (1 1/2" Chrome)
G#5	PT608-B55GC	G#5 Chime Tube (1 1/2" Chrome)
A5	PT608-B05AC	A5 Chime Tube (1 1/2" Chrome)
A#5	PT608-B55AC	A#5 Chime Tube (1 1/2" Chrome)
B5	PT608-B05BC	B5 Chime Tube (1 1/2" Chrome)
C6	PT608-B06CC	C6 Chime Tube (1 1/2" Chrome)




C#6	PT608-B56CC	C#6 Chime Tube (1 ½" Chrome)
D6	PT608-B06DC	D6 Chime Tube (1 ½" Chrome)
D#6	PT608-B56DC	D#6 Chime Tube (1 ½" Chrome)
E6	PT608-B06EC	E6 Chime Tube (1 ½" Chrome)
F6	PT608-B06FC	F6 Chime Tube (1 ½" Chrome)

## 1. PTC6618-BA Component Detail:

Note	Part Number	Description
C5	PT608-B05CB	C5 Chime Tube (1 ½" Brass)
C#5	PT608-B55CB	C#5 Chime Tube (1 ½" Brass)
D5	PT608-B05DB	D5 Chime Tube (1 ½" Brass)
D#5	PT608-B55DB	D#5 Chime Tube (1 ½" Brass)
E5	PT608-B05EB	E5 Chime Tube (1 ½" Brass)
F5	PT608-B05FB	F5 Chime Tube (1 ½" Brass)
F#5	PT608-B55FB	F#5 Chime Tube (1 ½" Brass)
G5	PT608-B05GB	G5 Chime Tube (1 ½" Brass)
G#5	PT608-B55GB	G#5 Chime Tube (1 ½" Brass)
A5	PT608-B05AB	A5 Chime Tube (1 ½" Brass)
A#5	PT608-B55AB	A#5 Chime Tube (1 ½" Brass)
B5	PT608-B05BB	B5 Chime Tube (1 ½" Brass)
C6	PT608-B06CB	C6 Chime Tube (1 ½" Brass)
C#6	PT608-B56CB	C#6 Chime Tube (1 ½" Brass)
D6	PT608-B06DB	D6 Chime Tube (1 ½" Brass)
D#6	PT608-B56DB	D#6 Chime Tube (1 ½" Brass)
E6	PT608-B06EB	E6 Chime Tube (1 ½" Brass)
F6	PT608-B06FB	F6 Chime Tube (1 ½" Brass)

Note	Part Number	Description
1-1	PC6518-258	Bar Cord
1-2	PC6518-021	Terminal Part

2




## 2. PCC1618A Component Detail:

Note	Part Number	Description
2-1	PC6618-004A	Hanger Assembly
2-2	PC1618-011	Frame Tube



2-3	<b>PC1618-101A</b>	Damper Box Complete(for Lacquered Tubes)
2-3	<b>PC1618C-101A</b>	Damper Box Complete(For Chrome-Plated Tubes)
2-4	PC1518-001LA	Leg Assembly (left)
2-5	PC1518-001RA	Leg Assembly (right)
2-6	<b>PC1618-635BA</b>	Pedal Crossbar
2-7	PC1518-3780A	Pull Rod Assembly Complete
2-8	PC1518-220A	Pedal Assembly
2-9	PC6618-3780A	Crossbar Assembly Complete
2-10	<b>PC1618-636BA</b>	Lower Crossbar


2-1



**2-1. PC6618-004A Component Detail:**

Note	Part Number	Description
2-1	<b>PC6618-004A</b>	Hanger Assembly
2-1-1	PJZ0800230A	Wing Bolt


2-2



### 2-5. **PC1618-011** Component Detail

Note	Part Number	Description
2-2	<b>PC1618-011</b>	Frame Tube

2-3




### 2-3. **PC1618-101A** Component Detail

Note	Part Number	Description
------	-------------	-------------



2-3	PC1618-101A	Damper Box Complete(for Lacquered Tubes)
2-3	PC1618C-101A	Damper Box Complete(For Chrome-Plated Tubes)
2-3-1	PJZ0800230A	Wing Bolt
2-3-2	PC6618-785	Mute Strip




**2-4. PC1518-001LA Component Detail**

Note	Part Number	Description
------	-------------	-------------




2-4	PC1518-001LA	Leg Assembly (left)
2-4-1	PJZ0800230A	Wing Bolt
2-4-2	PJZ0800300A	Wing Bolt



## 2-5. PC1518-001RA Component Detail


Note	Part Number	Description
2-5	PC1518-001RA	Leg Assembly (right)
2-5-1	PL450-251B	8" Pneumatic Wheel
2-5-2	PL450-252B	8" Locking Pneumatic Wheel
	PSDJ0800200BA	Socket Screw For Wheel



2-6

**2-6. PC1618-635BA Component Detail**

Note	Part Number	Description
2-6	PC1618-635BA	Pedal Crossbar




2-7

**2-7. PC1618-3780A Component Detail**

Note	Part Number	Description
2-7	PC1618-3780A	Pull Rod Assembly Complete
2-7-1	PC1618-380A	Upper Pull Rod Assembly




2-7-2	PJZ0600150A	Wing Screw
2-7-3	PC1618-370A	Lower Pull Rod Assembly
2-7-4	PWK22008215B	Flat Washer
2-7-5	PSH080030013	Hex Head Bolt



**2-8. PC1618-220A Component Detail**

Note	Part Number	Description
2-8	PC1618-220A	Pedal Assembly
2-8-1	PSC0600450HB	Allen Bolt
2-8-2	PWK15006220B	Flat Washer
2-8-3	PJZ0600150A	Wing Screw


2-9



## 2-9. PC6618-3780A Component Detail

Note	Part Number	Description
2-9	PC6618-3780A	Crossbar Assembly Complete
2-9-1	PJZ0800170A	Wing Bolt
2-9-2	PNH080006512	Hexagonal Nut

2-10




## 2-10. PC1518-636BA Component Detail

Note	Part Number	Description
2-10	PC1518-636BA	Lower Crossbar




3



**3. PC6618-505 Component Detail**

Note	Part Number	Description
3	PC6618-505	Majestic Chime Mallet
3-1	PC6618-265	Cowskin

4



**4. PC6618-X60C Component Detail**

Note	Part Number	Description
4	PC6618-X60C	Majestic Chime Cover