

majestic.

majestic®

Deluxe Vibraphone

V6530S


Spare Part Manual





Item	Part No.	Description
1	PBV6530-AAA	Tone BarSet (incl. Cords, Springs & Packaging)
2	PRV6530A-A01SL	V6530 Resonator Sets (Incl. Packaging) (不含外箱)
3	PFV6530-AAA	Frame (Incl. all hardware & packaging)
4	PLX6535-002A	Leg Assembly (Incl. Packaging, no cross rail)

1. V6530S Tone Bar Set



Item	Note	Part No.
1	F#3	PB705-A53F
2	G#3	PB705-A53G
3	A#3	PB705-A53A
4	C#4	PB705-A54C
5	D#4	PB705-A54D
6	F#4	PB705-A54F
7	G#4	PB705-A54G
8	A#4	PB705-A54A
9	C#5	PB705-A55C
10	D#5	PB705-A55D
11	F#5	PB705-A55F


Item	Note	Part No.
20	C4	PB705-A04C
21	D4	PB705-A04D
22	E4	PB705-A04E
23	F4	PB705-A04F
24	G4	PB705-A04G
25	A4	PB705-A04A
26	B4	PB705-A04B
27	C5	PB705-A05C
28	D5	PB705-A05D
29	E5	PB705-A05E
30	F5	PB705-A05F




12	G#5	PB705-A55G		31	G5	PB705-A05G
13	A#5	PB705-A55A		32	A5	PB705-A05A
14	C#6	PB705-A56C		33	B5	PB705-A05B
15	D#6	PB705-A56D		34	C6	PB705-A06C
16	F3	PB705-A03F		35	D6	PB705-A06D
17	G3	PB705-A03G		36	E6	PB705-A06E
18	A3	PB705-A03A		37	F6	PB705-A06F
19	B3	PB705-A03B				

Item	Part No.	Description
	PBV6530-156A	Tone Bar Cord & Springs Replacement package


2.V6530S Resonators






Item	Part No.	Description
	PRV6530AQ-ASN	V6530 Resonator Naturals
	PRV6530AB-ASN	V6530 Resonator Accidentals
1	PR705-040S	Mount Plate
2	PRV6530-041S	Mount Plate
3	PRV6530-040S	Mount Plate
4	PR415-601	Resonator Cap
5	PR320-601	Resonator Cap
6	PMP26-265	Rubber Bush
7	PRV7530-020	共鸣管活页转轴间座
8	PRV6530-240	Rubber Bush
9	PRV7530-304	Leaf Blades
10	PRV7530-303	Leaf Blades
11	PRV6530-300	Axis
12	PRV7530-548	Pulley
13	PRV6530-818	O Ring

3. V6530S Frame







Item	Part No.	Description
1	PF415-265	Resonance tube holder
2	PFV6530-564LB	Spring mounts
3	PF704-563	Spring
4	PF705-139	Bracket

5	PF705-140	Bracket
6	PFV6530-564HB	Spring mounts
7	PF704-561	Fixed plate
8	PFV6530-900	Screw
9	PF704-575	Adjusting nut
10	PFV6530-780B1	Tube
11	PF704-785	Felt
12	PF704-783	Bracket
13	PMV6530-256A	Belt
14	PF704-047A	Cover
15	PF450-533	Tone Bar Post (I Type)
16	PF450-301	Insulation for Bar Post (I Type)
17	PF420-533Y	Tone Bar Post (Y Type)
18	PFX6535-302	TPR Bush for Bar Post
19	PF420-533P	Tone Bar Post (P Type)
20	PFV6530-319	Axis
21	PFV6530-3201	Shaft seat
22	P2402-330	Felt
23	PWK10506215	Flat Washer
24	PWS10526312	Spring washer
25	PNW060006030	Wing Screw
26	PFV6530-603	Ring lugs Screw


4. V6530S Leg Assembly




(4-1)




(4-1-1)




(4-1-2)



(4-1-3)



(4-1-4)



No.	Part Number	Description
4--1	PLX6535-002A	Leg Assembly
4--1--1		
4-1-1-1	PMT26-312	Nylon Ring
4-1-1-2	PLM6543-275	Rubber Pad
4-1-1-3	PLM6543-270B	Connector
4-1-1-4	PLM6543-151B	Gear Box Cap
4-1-1-5	PSD0400080	Socket Screw
4-1-1-6	PLM6543-021	Plastic Washer
4-1-1-7	PLX6535-937	Crank Handle
4-1-1-8	PLM6543-938	Handle
4-1-1-9	PSDJ0800200BA	Socket Screw
4-1-1-10	PLM6543-150B	Leg Assembly
4-1-1-11	PLM6543-325	Tooth Gear
4-1-1-12	PLM6543-022	Plastic Washer
4-1-1-13	PWS10006220B	Spring Washer
4-1-1-14	PWK12006515B	Flat Washer
4-1-1-15	PNP060005810B	Lock Nuts(M6*8H*13W)
4-1-1-16	P14L1027B	Hex Screw
4-1-1-17	PPS0500060	Pin
4-1-1-18	P90SR037BZ	Screw M4*25
4--1-2		
4-1-2-1	PSDJ0800200BA	Socket Screw
4-1-2-2	PLM6543-070	Bush
4-1-2-3	P13L1007B	Hex Screw(M8X40L)
4-1-2-4	PLM6543-655B	Support
4-1-2-5	PL470-301	Bush
4-1-2-6	PLM6543-055B	Housing
4--1-3		
4-1-3-1	PFC0800300	Hex Screw(M8X30L)
4-1-3-2	PLM6543-001B	Bass
4-1-3-3	PSDJ0800200BA	Socket Screw
4-1-3-4	PL470-301	Bush
4-1-3-5	PL6543-252	4" Whell with Break
4-1-3-6	PL6543-251	4" Whell
4--1-4		
4-1-4-1	PLM6543-325	Tooth Gear
4-1-4-2	PLM6543-020	Plastic Washer
4-1-4-3	PLX6535-120	Screw



4-1-4-4	PLM6543-050B	Lower Section
4-1-4-5	PLX6535-088A	Rod
4-1-4-6	PSDJ0800200BA	Socket Screw
4-1-4-7	PLM6543-071	Bush
4—2	P13L1007B	Hex Screw (M8*40L)
4—3	PLM6543-024B	Leg Support
4—4	PLV6530-635BH1	Cross Raill
4---5	PLV6530-202BH	Damper Control tube
4---6	PLV6530-089	Casing
4---7	PE015-601	Plugs